



Application examples

- Small industrial scale for pharmacies
- · Hand mixtures of tea, coffee, chocolates
- · Portioning of dough, meat, fish, poultry, mixed salads in cafeterias etc.
- Mobile weighing of freshly picked fruit on site
- Checkweigher in supermarkets
- · High-precision industrial applications, piece counting or stock-taking

Official verification duty for commercial trade

Checkweighing and portioning scale, also with EC type approval [M]

Features

- · Compact size, practical for small spaces
- High mobility: thanks to rechargeable battery operation (optional), compact, lightweight construction, it is suitable for the use in several locations (production, warehouse, dispatch department etc.)
- Weighing with tolerance range (checkweighing): a visual and audible signal helps with portioning, dispensing or grading
- · Totalising of weights

Technical data

- · Large backlit LCD display, digit height 24 mm
- · Dimensions weighing surface, stainless steel, W×D 294×225 mm

- Overall dimensions W×D×H 320×330×125 mm
- Net weight approx. 3 kg
- Permissible ambient temperature GAB-N: 0°C/40°C GAB-M: -10°C/40°C

Accessories

- · Protective working cover, standard, can be re-ordered, scope of delivery: 5 items, KERN CFS-A02S05
- Signal lamp for visual support of weighing with tolerance range, KERN CFS-A03
- Rechargeable battery pack internal, operating time up to 90 h without backlight, charging time approx. 12 h, KERN GAB-A04

- Y-cable for parallel connection of two terminal devices to the RS-232 interface on the scale, e.g. signal lamp or barcode reader and printer, KERN CFS-A04
- Tare pan made of stainless steel, ideal for weighing loose small parts, fruit, vegetables etc., W×D×H 370×240×20 mm, KERN RFS-A02
- WLAN interface for wireless connection of the balance to networks and WLAN capable devices, such as tablets, laptops or smartphones, KERN CFS-A05
- · Further details, plenty of further accessories and suitable printers see Accessories

STANDARD



































Model	Weighing range	Readout	Verification	Minimal	Smallest part	Options			
			value	load	weight	Verification		DAkkS Calibr. Certificate	
	[Max]	[d]	[e]	[Min]	[counting]	MIII		DKD	
KERN	kg	g	g	g	g/piece	KERN		KERN	
GAB 6K0.05N	6	0,05	ı	1	0,05	-		963-128	
GAB 12K0.1N	12	0,1	-	-	0,1	-		963-128	
GAB 30K0.2N	30	0,2	ı	1	0,2	-		963-128	

Dual-range balance switches automatically to the next largest weighing range [Max] and readout [d]

Note: For applications that require verification, please order verification at the same time, initial verification at a later date is not possible. Verification at the factory, we need to know the full address of the location of use

To model of at the factory, we need to know the factor of the foods of											
GAB 6K1DNM	3 6	1 2	1 2	20	0,2	965-228	963-128				
GAB 15K2DNM	6 15	2 5	2 5	40	0,5	965-228	963-128				
GAB 30K5DNM	15 30	5 10	5 10	100	1	965-228	963-128				

KERN Pictograms:



Internal adjusting: Quick setting up of the balance's accuracy with internal adjusting weight (motodriven).



Piece counting: Reference quantities selectable. Display can be switched from piece to weight



Rechargeable battery pack: Rechargeable set

C) EU, GB, CH, USA, AUS



Adjusting program CAL: For quick setting up of the balance's accuracy. External adjusting weight required.



Recipe level A: Separate memory for the weight of the tare container and the recipe RECIPE ingredients (net total).



Universal mains adapter: with universal input and optional input socket adapters for A) EU, GB B) EU, GB, CH, USA



Memory: Balance memory capacity, e.g. for article data, weighing data, tare weights, PLU etc.



Recipe level B: Internal memory for complete recipes with name and target value of the recipe ingredients. User guidance through display.



Mains adapter: 230V/50Hz in standard version for EU. On request GB, USA or AUS version available



Alibi memory: Electronic archiving of weighing results, complying with the 2014/31/EU standard.



Recipe level C: Internal memory for complete recipes with name and target value of the recipe ingredients. User guidance through display, multiplier function, adjustment of recipe when dosages are exceeded or barcode



Power supply: Integrated in balance. 230V/50Hz standard EU. More standards e.g. GB, USA or AUS on request.

Weighing principle: Strain gauge

Electrical resistor on an elastic

excited, causing it to oscillate.

deforming body



Data interface RS-232: To connect the balance to a printer, PC or network.



SUM

Totalising level A: The weights of similar items can be added together and the total can be printed out.



Weighing principle: Tuning fork A resonating body is electromagnetically



RS 485

ance against electromagnetic disturbance. USB data interface: To connect the balance to a printer, PC or other peripherals.

RS-485 data interface : To connect the balance

to a printer, PC or other peripherals. High toler



Percentage determination: Determining the deviation in % from the target value



Weighing principle: Electromagnetic force compensation Coil inside a permanent magnet. For the most accurate weighings



Bluetooth* data interface: To transfer data from the balance to a printer, PC or other peripherals.



Weighing units: Can be switched to e.g. nonmetric units at the touch of a key. See balance model. Please refer to KERN's website for more details.




Weighing principle: Single cell technology Advanced version of the force compensation principle with the highest level of precision



WLAN data interface: To transfer data from the balance to a printer, PC or other peripherals.



Weighing with tolerance range: Upper and lower limiting values can be prgrammed individually for e.g. dosing, sorting and portioning



Verification possible: The time required for verification is specified



Control outputs (optocoupler, digital I/O) : To connect relays, signal lamps, valves, etc.



Hold function: (Animal weighing program) When the weighing conditions are untable, a stable weight is calculated as an average



DAkkS calibration possible (DKD) : The time required for DAkkS calibration is shown in days in the pictogram



Interface for second balance : For direct connection of a second balance



Protection against dust and water splashes IPxx: The type of protection is shown in the pictogram.



Package shipment: The time required for internal shipping preparations is shown in days in the pictogram



Network interface: For connecting the scale to an Ethernet network. With KERN products you can use a universal RS-232/LAN converter.



ATEX explosion protection: Suitable for use in hazardous industrial environments, in which there is explosion danger. The ATEX marking is specified for each device



Pallet shipment: The time required for inter nal shipping preparations is shown in days in the pictogram.



Wireless data transfer : between the weighing unit and the evaluation unit using an integrated radio module.



Stainless steel : The balance is protected against corrosion.



Warranty: The warranty period is shown in the pictogram



GLP

GLP/ISO log: The balance displays the weight, date and time, regardless of a printer connection.



Suspended weighing: Load support with hook on the underside of the balance



GLP/ISO log: With weight, date and time. Only with KERN printers.



Battery operation: Ready for battery operation. The battery type is specified for each device

KERN – Precision is our business

To ensure the high precision of your balance KERN offers you the the appropriate test weight in the international OIML error limit classes E1-M3 from 1 mg - 2500 kg. In combination with a DAkkS calibration certificate the best pre-requisite for proper balance calibration.

The KERN DAkkS calibration laboratory today is one of the most modern and best-equipped DAkkS calibration laboratories for balances, test weights and forcemeasurement in Europe.

Thanks to the high level of automation, we can carry out DAkkS calibration of balances, test weights and force-measuring devices 24 hours a day, 7 days a week.

Range of services:

- DAkkS calibration of balances with a maximum load of up to 50 t
- DAkkS calibration of weights in the range of 1 mg 2500 kg
- · Volume determination and measuring of magnetic susceptibility (magnetic characteristics) for test weights
- Database supported management of checking equipment and reminder service
- Calibration of force-measuring devices
- DAkkS calibration certificates in the following languages DE, GB, FR, IT, ES, NL, PL
- · Conformity evaluation and reverification of balances and test weights

Your KERN specialist dealer:

Impex Produkter AS Gamle Drammensvei 107 **1363 HØVIK** Tel. 22 32 77 20 info@impex.no www.impex.no